

## Safe Box.

### HOW TO USE YOUR SAFEBOX

Shila will keep your valuable items secure.

#### STEPS

1. Push the red button which is behind the box door and close.
2. In five seconds set a 3-8 digit number (new password) by pressing the numbers and then press E to confirm.
3. Turn the knob left (counterclockwise) to secure the door.
4. To open it, enter the password you set before and press the E button.
5. When the green light is on, turn the knob right (clockwise) within five seconds to open the safe box.

If you are unable to open your safe box or encounter any issues, please contact the front desk for assistance.